


ENG

MINI Bluetooth Speaker

User Manual



1. Speaker
2. Hole for cord
3. LED indicator
4. Button
5. Microphone
6. Micro USB socket

4. Turn off the speaker by pressing "⏻" button for 4 seconds and the speaker will sound "DI DO". When disconnected, this speaker will turn off after 5 minutes.

Note: 1. When you can't take a photo, under the Android system, please open "Settings"-"Camera", then set "Volume key" to "Shutter"; under the IOS system, you just need to refresh the Bluetooth connection.

2. When you can't play the music, please refresh the Bluetooth connection.

3. **Transfer between selfie mode and keyboard mode**
Double click "⏻" button of main speaker to transfer the selfie mode and keyboard mode (you will hear a sound which like taking picture or keyboard). Under selfie mode, one click to take a photo when open camera APP. (If close camera APP, continuous click to up volume) Under keyboard mode, one click to Play/Pause.

Note: It is keyboard mode when open speakers by default!

4. Selfie function is not compliant for all mobile function.

Charging the battery:

Insert the charging cable into the Micro USB input port, connect the USB plug into 5V/800mA USB power terminal. The LED indicator will turn red.

Bluetooth pairing for music / phone call / camera remote shutter

1. Turn on the speaker by pressing "⏻" button for 3 seconds. The speaker will have a voice prompt and blue indicator will flash.
2. Turn on your device and activate the Bluetooth function.
3. Search for Bluetooth pairing name "SINGSONG" and click to pair, the speaker will pair automatically and the speaker will have a voice prompt, the blue indicator will light on. Then, just need to press "⏻" button to answer the call when the call is coming or take a photo when open the camera of your devices.

Stereo Mode (only for two speakers):

Power on the two speakers. Double press "⏻" on one speaker. You will hear a sound when playing with success. At that time the main speaker will flash and the other will light up.

After the first pairing, the SING SONG will connect directly when turned on at the same time (they will recognize each other after the first use).


Specification:

Power Rating	P0 = 3W
Transmitting Frequency	20HZ-20KHZ
THD	< 1%
S/N	≥ 80DB
Speaker Parameter	4Ω 3W diameter 33mm
Battery	3.7V/400mAh
Bluetooth Version	Bluetooth V5.0
Product Size	Φ42.5 × 45mm
Product Weight	40.5g

FR

MINI Enceinte Bluetooth

Manuel d'utilisation



1. Haut-parleur
2. Trou pour cordon
3. Indicateur LED
4. Bouton
5. Microphone
6. Port micro USB

4. Eteindre l'enceinte en appuyant sur le bouton « ⏻ » pendant 4 secondes. L'enceinte émettra le son « DI DO ». Lorsque l'enceinte est déconnectée, elle s'éteint au bout de 5 minutes.

Note :

1. Lorsque vous prenez une photo sous un système Android, il faut ouvrir les réglages de l'appareil photo et activer l'option « touche volume en tant qu'obturateur ». Rafraîchir ensuite la connexion Bluetooth.
2. Si la musique ne se lance pas sur l'enceinte, rafraîchir la connexion Bluetooth.
3. **Passer du mode selfie au mode clavier:**
Double cliquer sur le bouton « ⏻ » de l'enceinte afin de passer en mode selfie ou clavier (vous entendrez le son d'une prise de photo ou de clavier). En mode selfie, un clic suffit pour prendre une photo lorsque l'appareil photo est lancé (lorsqu'il est éteint, les clics en continu augmentent le volume); en mode clavier un clic met en pause ou play.
Note: Le clavier est le mode par défaut lorsque l'enceinte s'allume.
4. La fonction appareil photo ne convient pas à tous les téléphones

Pour charger la batterie :

Insérer le câble de chargement dans le port micro USB, puis connecter ce câble à un terminal USB 5V/800mA. L'indicateur LED deviendra rouge.

Jumelage Bluetooth pour la musique / les appels / appareil photo à distance

1. Allumer l'enceinte en appuyant sur le bouton « ⏻ » pendant 3 secondes, l'enceinte émettra un son vocal et l'indicateur bleu clignotera.
2. Allumer votre appareil et activer la fonction Bluetooth.
3. Rechercher le nom d'appariement « SING SONG » et sélectionner le pour jumeler les appareils. L'enceinte émettra un son vocal et l'indicateur bleu s'allumera complètement. Ensuite, il suffit de presser le bouton « ⏻ » pour répondre à un appel lorsque le téléphone reçoit un appel ou pour prendre une photo lorsque l'appareil photo est allumé sur votre appareil.

Mode Stéréo (avec 2 appareils connectés):

Les deux SING SONG doivent être allumés. Double-cliquer sur sur l'un des 2 appareils. Il y a un son lorsqu'ils sont couplés avec succès. À ce moment-là le haut-parleur principal va clignoter et

l'autre s'allumer. Après le premier jumelage les SING SONG se connecteront directement lorsqu'ils seront allumés en même temps (ils se reconnaîtront après la première utilisation).

Specification:

Puissance nominale	P0 = 3W
Fréquence de transmission	20HZ-20KHZ
THD (taux de distorsion harmonique)	< 1%
S/N	≥ 80DB
Paramètre de l'enceinte	4Ω 3W diameter 33mm
Batterie	3.7V/400mAh
Version Bluetooth	Bluetooth V5.0
Dimensions Produit	Φ42.5 × 45mm
Poids Produit	40.5g